





Length of profile	Number of suspension kit
L < 1695	2
1695 < L < 2830	3



G440CKW








N = L2/L1L1=1200-1800 L3= MIN. = 200 / MAX. = L1 / 2 For Example: L2 = 10000 ,L1=1500 \rightarrow N= $\frac{10000}{1500}$ =6.666)

L3=(0.666*1500) /2 =50mm



Number of Instalation Kit: 6


Instruction for Installation and Utilization of INFINITY-C Surface Mount or Suspension Light Bar

7002013413

www.megalite.com info@megalite.com










- 2- Earth connection as provided is mandatory.
- 3- Do not directly touch or impact LED module.
- 4- Do not stare at LED light source.
- 5- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. Always switch off the power prior to installation, maintenance or repair activities.





Cat. No.	L	تعداد براکت نصب Number of installation bracket	W (kg)
M440C601LED2AF	580	2	2.5
M440C902LED2AF	860	2	3.5
M440C1152LED2AF	1140	2	4.5
M440C1453LED2AF	1425	2	5.0
M440C1703LED2AF	1705	3	5.5
M440C2004LED2AF	1985	3	6.5
M440C2304LED2AF	2265	3	7.5
























No. Minutes: CM-94-452 Doc. No.W-CM011/01 Execution Date: 05/09/2015 Tracking Code: TM-9026/5

Instruction for installation and utilization of *INFINITY-C* surface mount or suspension continuous light bar








- 3- Do not directly touch or impact LED module.
- 4- Do not stare at LED light source.
- 5- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. Always switch off the power prior to installation, maintenance or repair activities.








In order to prevent lighting from seeping through the cracks and crevasses of the profile, you must adhere the stickers on the inside crevasses.


diffuser in every 3m lumianire length


Consider 1mm space between housing profile and














Terminal base mounting







440CKSF


Mounting brackets





3



























4






Number of Instalation Kit:1+6=7















- 1- For proper utilization of this product and for safety, it is mandatory to closely comply with the directions and notes in this installation and maintenance guide.
 2- Earth connection as provided is mandatory.
 3- Do not directly touch or impact LED module.
 4- Do not stare at LED light source.




Attention!




Dispart the wires from the last terminal at the end




Cut the terminal wires as needed at the jointed connectors.





Consider 1mm space between housing profile and diffuser in every 3m lumianire length








Gear tray placement as a sample in fluorescent models with diffuser


























7