




440CKSU...












Cat. No	L	Number of installation kit
M440E601LED2AF	580	2
M440E902LED2AF	860	2
M440E1152LED2AF	1140	2
M440E1453LED2AF	1425	2
M440E1703LED2AF	1705	2
M440E2004LED2AF	1985	3
M440E2304LED2AF	2265	3




Instruction for Installation and Utilization of INFINITY-E Surface Mount Light Bar









- 4- Do not stare at LED light source.







Cat. No	L	Number of installation bracket
M440E601LED2AF	580	2
M440E902LED2AF	860	2
M440E1152LED2AF	1140	2
M440E1453LED2AF	1425	2
M440E1703LED2AF	1705	2
M440E2004LED2AF	1985	3
M440E2304LED2AF	2265	3





200 ₩ ₩		→ 64
100	1 6 8 9	
*/_		







С









Max 12 mm











- 1- For proper utilization of this product and for safety, it is mandatory to closely comply with the directions and notes in this installation and maintenance guide.
 2- Earth connection as provided is mandatory.
 3- Do not directly touch or impact LED module.
 4- Do not stare at LED light source.







Dispart the wires from the last terminal at the end





Cut the terminal wires as needed at the jointed connectors.







Correct position of terminal














440CKSU...











Number of Instalation Kit:1+6=7

5

6







- 1- For proper utilization of this product and for safety, it is mandatory to closely comply with the directions and notes in this installation and maintenance guide.
 2- Earth connection as provided is mandatory.
 3- Do not directly touch or impact LED module.
 4- Do not stare at LED light source.

