


Instruction for Installation and Utilization of LEDISUN Industrial Luminaire


7002018910

Megalite Crafted for Brilliance

info@megalite.com		Cat. Code	Dimentions
		Cal. Code	D(mm)
		M309SEW1LED	320
		M309MEW1LED	360
0@U		M309LEW1LED	420
info		M309XLEW1LED	450
Ę			
www.megalite.com	 For proper utilization of this product and safety, it is mandatory to closely comply with the directions and notes in this instruction and guide. Earth connection as provided is mandatory. When various power loads exist, a separate switchboard including all protective equipment should be considered for the lighting system. 		

- 2- Earth connection as provided is mandatory.
- 3- When various power loads exist, a separate switchboard including all protective equipment should be considered for the lighting system.
- 4- During any construction process such as welding, etc., make sure that the luminaires are switched off or a stabilizer is used to prevent power disturbances leading to serious damage to the drivers or other electrical components.
- \mathbb{A} 5- Serious damage in electrical components will be caused by applying inappropriate voltage.
 - 6- When carrying out maintenance works on the luminaire, ensure that the sealing gaskets are in proper condition and IP is preserved.
 - 7- If a luminaire has a specified Ingress Protection rating, protection devices such as glands, etc., should be used to provide the desired IP.
 - 8- Do not stare at LED light source.
 - 9- Do not directly touch or impact LED module.





No. Minutes: CM-94-452 Doc. No.W-CM011/01 Execution Date: 05/09/2015 Tracking Code: DOC-334